



V1 = 12AX7 / ECC83	TR1 = 269EX
V2 = EL84/6BQ5	TR2 = P-T31

Voltages measured from test point to ground with **no signal** and the following front panel settings:

POWER: ON
 BASS: "0"
 TREBLE: "0"
 VOLUME: "0"



www.modkitsdiy.com
 Copyright © 2011 by modkitsdiy.com

K-MOD102 Schematic